
Head Voltage Calibration



Technical Support

Version # 1.0
Date: 4/5/12



Contact Info

Corporate Office: **AnaJet Inc.**
3050 Redhill Ave
Costa Mesa, CA 92626
USA

Telephone: **714.668.6000**
Toll Free: **877-6-ANAJET (877.626-2538)**
Fax: **714.662.3600**

Revision History

Revision	Description	Author	Date
1.0	Initial release.	Paul Green- Product Manager	4/5/12

Head Voltage Calibration

Introduction

This is a troubleshooting guide on how to resolve issues with resetting head voltage calibration

Scope

This applies to mPower printers only.

Symptoms


- Nozzle check prints no ink, blank pattern
- Missing channel ink nozzle check that will not return after multiple cleans

Possible causes


1. Printer needs to be re-booted, power down and power back up followed by a nozzle check
2. Print head voltage needs to be recalibrated:
 - Press Enter, Menu and Jobs at the same time on the control panel to take you into a different menu, only to be used when instructed to do so by technical support.




- Go to the Module Tests menu and press enter




- Go into the Print Head menu and press enter




- Go to Calibrate Head Voltage then press enter, wait for the calibration to complete and the pop up screen to go away
- Go to Generate Waveforms and press enter, the color will change from yellow to red.




- Go to Stop Amp and press enter, the color will change from yellow to red



- Go to Start Amp and press enter, color will change from yellow to red



- Go to Read Head Voltage to see if this worked and no values show zero.



- If all voltages read press the main menu button and do a print head clean 1 followed by a nozzle check
3. Ink has not yet reached the print heads and a print head clean should be performed followed by a nozzle check, repeat if necessary.